MIT OpenCourseWare <u>http://ocw.mit.edu</u>

6.189 Multicore Programming Primer, January (IAP) 2007

Please use the following citation format:

Saman Amarasinghe and Rodric Rabbah, *6.189 Multicore Programming Primer, January (IAP) 2007.* (Massachusetts Institute of Technology: MIT OpenCourseWare). <u>http://ocw.mit.edu</u> (accessed MM DD, YYYY). License: Creative Commons Attribution-Noncommercial-Share Alike.

Note: Please use the actual date you accessed this material in your citation.

For more information about citing these materials or our Terms of Use, visit: <u>http://ocw.mit.edu/terms</u>

# **Cell programming mini-reference**

## **Cell documentation**

Most of the documentation for Cell is at http://www-

<u>128.ibm.com/developerworks/power/cell/</u>. Click on the <u>Docs</u> tab, then click on <u>Documentation archive</u>. When browsing through the PDF documentation, Acrobat's Bookmarks tab contains the table of contents. For library references, this contains a listing of all functions.

<u>SPE runtime management library</u> (currently the 4th entry in the list) contains information on the SPE management functions (libspe) available to the PPU.

<u>PPU & SPU C/C++ language extension specification</u> (5th entry) contains information on the basic library available to SPU programs (DMA/mailbox access functions, vector data types and intrinsics).

<u>SIMD math library specification</u> contains information on SIMD math functions available to both SPU and PPU programs.

For information on other libraries available on the SPU, look at <u>/opt/ibm/cell-</u> <u>sdk/prototype/docs/libraries\_SDK.pdf</u> on the PS3. The header files in <u>/usr/spu/include/</u> may also be useful, especially for the SIMD math functions.

More detailed information about Cell is available in the <u>Cell Broadband Engine</u> <u>programming handbook</u> and Cell Broadband Engine Architecture.

## **SPE thread issues**

SPE threads behave differently from "normal" threads. The OS currently runs SPE threads on physical SPEs in FIFO order (with some exceptions): SPE threads are not preempted, and if more SPE threads are created than there are physical SPEs, the extra threads will wait until the running threads have exited (i.e., returned from main) before they begin executing. This applies across SPE threads from all processes: if one process is using all SPEs, no other process can use the SPEs. When an SPU program stalls due to a mailbox or signal notification register access or DMA completion wait, it still occupies its SPE.

Generally, this means that you shouldn't create more threads than there are SPEs. Only 6 SPEs are enabled on the PS3s.

# **DMA** issues

(A word on Cell is 4 bytes; the documentation often refers to quadwords, which are 16 bytes.)

# Alignment

DMA transfers must be a multiple of 16 bytes (up to a maximum of 16 KB) and *aligned* on a 16 byte boundary (i.e., the local store and memory addresses the DMA starts at must both be divisible by 16).

Alternatively, Cell also supports DMA transfers of 1, 2, 4, or 8 bytes that are *naturally aligned* (the starting local store and memory addresses must be divisible by the size of the transfer) and have the same local store and memory address offsets with a 16-byte block (e.g., local store address mod 16 = memory address mod 16).

Transfers of 16 bytes or less are *atomic*: all processors observe the transfer as occuring in a single operation. For larger transfers, processors may be able to observe that e.g. the first 16 bytes of the transfer have occured but the rest has not.

# Structure padding

Use the aligned attribute:

```
__attribute__((aligned(n)))
```

to pad and align structure declarations to a multiple of n bytes (must be a power of 2, within reasonable limits).

```
struct S {
    int a, b, c;
} __attribute__((aligned(16)));
```

This pads the size of the structure to a multiple of 16 bytes (sizeof(struct S) becomes 16 instead of 12), and ensures that all variables of this type are 16-byte aligned.

# Dynamic allocation

malloc on the SPEs allocates memory that is 8-byte aligned. To allocate memory with larger alignments (on both the SPU and PPU), use malloc\_align:

```
void *malloc_align(size_t size, unsigned int n)
```

which allocates memory that is 2<sup>n</sup>-byte aligned (free this memory using free\_align). To use malloc\_align/free\_align, you must #include <libmisc.h> and link with libmisc (add -lmisc to the IMPORTS variable in your SPU program makefile).

## **SPE management functions**

This section describes some useful SPE management functions. These functions are part of libspe and are available only to the PPU.

Full documentation for libspe is in the <u>SPE runtime management library</u> document.

## Thread management

```
spe_create_thread(gid, program, argp, envp, -1, flags)
```

Creates (and starts, if a physical SPE is available) an SPE thread running program.

- gid specifies the thread group (see spe\_create\_group); specify 0 if you're not interested (this creates a new thread group)
- argp and envp are passed to the SPU program's main function
- flags can be 0, or SPE\_MAP\_PS if other SPEs need to access the mailboxes/signals of this program. There are also other flags (see documentation).

Returns the thread ID (an opaque value).

```
spe_wait(speid, NULL, options)
```

Waits or polls for SPE thread speid to exit.

• options can be 0 to wait or WNOHANG to poll

```
spe_get_ls(speid)
```

Returns the address of SPE thread speid's local store. The PPU or other SPUs can use this address to access this SPE's local store.

spe\_get\_ps\_area

Returns the address of an SPE thread's mailboxes and signal notification registers (see documentation). Other SPUs can use this address to write to this SPE's mailboxes/signals.

#### Mailboxes

```
spe_write_in_mbox(speid, data)
```

Writes data to SPE thread speid's inbound mailbox. Does not stall; overwrites last entry if no space is available.

```
spe_stat_in_mbox(speid)
```

Returns the space available in SPE thread speid's inbound mailbox. This is the number of times spe\_write\_in\_mbox can be safely called without overwriting an entry.

spe\_read\_out\_mbox(speid)

Reads from SPE thread speid's outbound mailbox. Does not stall; returns -1 if no entry is present.

spe\_stat\_out\_mbox(speid)

Returns the number of entries present in SPE thread speid's mailbox. This is the number of times spe\_read\_out\_mbox can be safely called. This is always 0 or 1, since the outbound mailbox has capacity for only one entry.

#### DMA

spe\_mfc\_get
spe\_mfc\_put
spe\_mfc\_read\_tag\_status

Analogous to SPU's DMA functions (see documentation).

## **SPU functions**

This section describes some useful DMA and communication functions for SPU programs. Full documentation is in section 4 of the <u>PPU & SPU C/C++ language</u> <u>extension specification</u>.

#### DMA

```
mfc_get(dest_lsa, src_addr, num_bytes, tag, 0, 0)
mfc_put(src_lsa, dest_addr, num_bytes, tag, 0, 0)
```

Starts a DMA transfer.

• tag specifies a 5-bit (0 - 31) tag for the transfer

#### DMA completion

```
mfc_write_tag_mask(mask)
```

Writes a mask specifying the DMA tags subsequent mfc\_read\_tag\_status\* calls wait for.

```
mfc_read_tag_status_all()
```

Waits until DMA transfers using every tag in the last specified tag mask have completed.

```
mfc_read_tag_status_any()
```

Waits until any tag in the last specified tag mask has completed.

```
mfc_read_tag_status_immediate()
```

Returns a mask indicating the tags in the last specified tag mask that have completed. Does not stall.

## Mailboxes

```
spu_read_in_mbox()
```

Reads from the inbound mailbox. Stalls until an entry is present.

```
spu_stat_in_mbox()
```

Returns the number of entries present in the inbound mailbox. This is the number of times spu\_stat\_in\_mbox can be safely called without stalling.

```
spu_write_out_mbox(data)
```

Writes data to the outbound mailbox. Stalls until space is available.

```
spu_stat_out_mbox()
```

Returns the space available in the outbound mailbox. This is the number of times spu\_write\_out\_mbox can be safely called without stalling. This is always 0 or 1, since the outbound mailbox has capacity for only one entry.